



Merrychef eikon® e4s

Ideal for quick service outlets
and convenience stores



Valid from 1st June 2025 until further notice

An all-round high speed oven, suitable for a busy kitchen.

- Icon driven easyTouch®1.0 controller.
- Unique internal grease filter reduces grease build-up.
- Up to 75% faster than other conventional cooking methods.
- 14" x 12" cavity in a 24" width oven.
- Merrychef DNA features (p2).

tri-pleX technology combines:



Microwave



Convection

with air accelerated
through an
impingement plate



Impingement

eikon® e4s

Color

Stainless steel

Dimensions (external) W x D x H 23" (584mm) x 25.3" (643mm) x 23.3" (591 mm) *(depth excludes handles)*

Dimensions (internal) W x D x H 14.7" (375mm) x 14.6" (370mm)

Model	Convection/ Microwave	Max. Power Input	Electrical Supply	Plug type	Price \$
eikon® e4s	3200 W/1800 W	6200 W	208 V / 240 V 60 Hz	NEMA 6-30P	29,613

Included accessories

▷ Wire rack

H1.4" x W14.4" x D13.5"
Part no: **PDV0908**




▷ Paddle without sides

W13" x D12.25"
Part no: **PSR310**



▷ Full size mesh cooking tray x2

H1" x W14.5" x D11.5"
Part no: **32Z4031**



▷ Cool down pan

1/2 size 4" deep
Part no: **32Z4028**



▷ Oven cleaner and protector pack

Pack of x1 32 fl oz cleaner
and x1 32 fl oz protector
Part no: **32Z4148**



Updated
branding?

- ▷ **Flat cook plate**
H1" x W14.5" x D14"
Part no: **DV0870**



\$239

- ▷ **Paddle with hand guard and sides**
W13" x D12.25"
Part no: **SR320**



\$226

- ▷ **Tray handle for use with DX0117**
H1" x W10.5" x D3.5"
Part no: **SR313**



\$164

- ▷ **Paddle without sides**
W13" x D12.25"
Part no: **PSR310**



\$209

- ▷ **Cool down pan**
1/2 size 4" deep
Part no: **32Z4028**




\$164

- ▷ **Non-stick baking/roasting tray**
H0.6" x W11.8" x D10.75"
Part no: **P40H0230**



\$164

- ▷ **Full size mesh cooking tray**
H1" x W14.5" x D11.5"
(Black) Part no: **32Z4031**



\$209

- ▷ **Cook plate ideal for pizzas**
H0.6" x W14.5" x D14"
Part no: **DV0880**



\$239

- ▷ **Griddled cook plate**
H1" x W14.5" x D11.5"
Part no: **DV0860**




\$660

- ▷ **Wire rack**
H1.4" x W14.4" x D13.5"
Part no: **PDV0908**



\$322

- ▷ **Wire rack**
H1.4" x W14.4" x D13.5"
Part no: **PDV0907**



\$255

- ▷ **Solid base tray full size**
H1" x W13.5" x D13.5"
(Black) Part no: **32Z4086**



\$209

- ▷ **Moveable oven trolley**
H19 x W30 x D24"
Part no: **STACK-19**



\$2,097

- ▷ **Moveable oven trolley**
H36 x W30 x D24"
Part no: **STACK-36**



\$3,705

- ▷ **Moveable oven trolley**
H see below x W25 x D26"
The bottom shelf may be adjusted to be 21 1/2", 20 1/4", or 19" above the ground, while the top shelf may also be adjusted to be 48 1/4", 47", or 45 3/4" above the ground. Each shelf is 25" wide.
Part no: **STACK-48**



\$6,153

- ▷ **Moveable oven trolley**
H47.25" x W27.5" x D27"
Part no: **40H0098**



\$5,511

- ▷ **Scraper**
Part no: **32Z4191**



\$13

- ▷ **Red brush (hard bristles)**
Part no: **32Z4189**



\$25

Accessories with ▶ can be used with any Merrychef oven if the dimensions fit the cavity. Additional signature range accessories suitable for this oven can be found in the Accessories brochure .